

Freevend Dispenser



TECHINICAL SPECS

HEIGHT: 500mm
WIDTH: 280mm
DEPTH: 100mm
WEIGHT: 9kg

DISPENSER CAPACITY

Left column	Right column
70 Towels	350 Tampons

The figures above are based on estimates only

HOW TO INSTALL THE FREEVEND

- Step 1: Hold the empty Period Product dispenser up on the wall where you would like to install your dispenser.
- Step 2: Using a pencil create a mark where the holes should be drilled.
- Step 3: Using a drill, begin drilling 4 holes where you have marked out on the wall (see diagram below for drill holes).
- Step 4: Insert a wall plug into each hole that has been drilled.
- Step 5: Using screws, hold your dispenser up to match up with the 4 holes that you have just drilled and add the screws (make sure these are tight to prevent the dispenser from falling).
- Step 6: When the dispenser is secure you can now add the pads and tampons for dispensing.

